



THE YEAR-END MAINTENANCE CHECKLIST FOR YOUR BOBCAT® FLEET

(PRINT THIS SHEET AND USE IT TO TRACK YOUR COMPLETED TASKS.)

SAFETY, SOFTWARE AND RECORDS

- ☐ Lockout/tagout, park on level ground, check wheels, let systems cool
- ☐ Pull fault codes and review Machine IQ notifications.
- ☐ Export annual maintenance logs for records and resale value.
- ☐ Check brake system, back up alarm and horn

POWERTRAIN

- ☐ Change engine oil and filter per hours or annually; sample oil if you ran heavy duty cycles this summer.
- ☐ Replace fuel filters; check water separators. Prime/bleed per procedure.
- ☐ Inspect air filters; replace if restriction indicator tripped.
- ☐ Compression or leak-down test on high-hour units before the busy season.

COOLING SYSTEM

- ☐ Pressure-test the system, inspect hoses, clamps and radiator fins.
- ☐ Test freeze point and corrosion protection; refresh coolant per interval.

HYDRAULIC & HYDROSTATIC

- ☐ Change hydraulic/hydrostatic filters and sample fluid; replace fluid at the specified hours.
- ☐ Inspect lines, quick couplers, cylinders and case drains for leaks or abrasion.

DRIVETRAIN & UNDERCARRIAGE

- ☐ For loaders: check chaincase or axle fluids; inspect sprockets, idlers, rollers and track tension.
- ☐ For track machines: inspect final drive gear oil and top off or replace per hours; confirm swivel joint is dry.

ELECTRICAL & STARTING

- ☐ Test battery health with a conductance tester; clean terminals; verify alternator output; inspect harness chafe points.
- ☐ Inspect work lights, beacon, camera and display panel.

FUEL & DEF

- ☐ Drain water from storage tanks; test for contamination.
- ☐ Store DEF in clean, sealed containers between 15° and 77°F, away from direct sun; avoid ferrous metals and concrete. Rotate stock to protect shelf life.

GREASE POINTS

- ☐ Grease all fittings with the correct spec; verify pins/bushings for play.

HYDRAULIC ATTACHMENTS

- ☐ Inspect cutting edges, teeth, auger drives, mulcher rotors and mower decks. Replace worn parts to protect carriers.

CABS & CONTROLS

- ☐ Check seat belts, lap bars, pedals, joysticks, backup alarm, mirrors, HVAC and defrosters. Replace cabin filters.

TIRES & TRACKS

- ☐ Set pressures; inspect sidewalls, tread and bead seats
- ☐ Set track tension to spec; under- or over-tensioning accelerates wear.

BUCKET & QUICK ATTACH

- ☐ Inspect coupler lock function; check for hairline cracks; measure cutting edge wear.

TELEMATICS & SECURITY

- ☐ Verify Machine IQ is connected on every unit; confirm geofences and maintenance alerts; test Remote Engine Disable/Enable on at least machine.